



# Toshiba Mini NB505 Battery Replacement

This guide consists of how to replace the battery

Written By: Michael Hamilton



## INTRODUCTION

Over time the battery will begin to not hold a charge as long as it use to or even at all. If you need to constantly have your laptop plugged in or it will not turn on, then the battery might need to be replaced. This guide will help you do just that!

## Step 1 — Battery



- Located on the bottom of the laptop, find the two tabs shown in the picture and push both of them outwards away from the battery.

## Step 2



- While pushing the tabs outwards, push on the raised bumps on the battery away from the laptop.



## Step 3



- The battery is now removed

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-21 08:37:39 AM.